



Fluke 77 Series III Battery Replacement

Replace the battery on the Fluke 77 Series III Multimeter.

Written By: Jessica Bombardier Shaw



INTRODUCTION

If the battery on your Fluke 77 Series III Multimeter needs to be replaced, this guide details the steps for doing so. Replacing the battery is a routine, but critical part replacement for the Fluke 77 Series III Multimeter.



TOOLS:

- [Phillips #2 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)



PARTS:

- [9V Battery](#) (1)

Step 1 — Front Panel



- ⚠ Be sure any test leads are out and the multimeter is off before opening the device.
- Turn the multimeter so it is display side down.
- Lift up the back stand of the device by putting your thumb in the curved well at the bottom of the device, so you have access to the two covered screws below.

Step 2



- Use your Phillips #2 Screwdriver to remove the four black 21 mm Phillips #2 screws.


Step 3



- Turn the Fluke 77 Series III Multimeter back over so that it is display side up.
- Pry the front panel from the back panel at the seam.
- If the front panel does not come off easily, move a plastic opening tool along the seam until the panels separate completely.



Step 4 — Battery



 When doing this next step, make sure to remove the battery slowly, so you don't damage the wires connecting the battery to the device.

- Locate the 9V battery in the lower right corner of the device.
- Pull the battery out of its terminal.

Step 5



 Only pull on the metal snaps and battery. Pulling the cords may damage them.

- Detach the two metal snaps from the battery.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-03 08:17:35 AM.